



INSTALLATION INSTRUCTIONS

**PART NUMBER: DHD19-100 GRILLE GUARD
DHD19-PB PUSH BAR
APPLICATION: 2019+ DODGE RAM 2500/5500**

QTY	PARTS LIST
1	DHD19-100/PB
6	½" x 1 ½" HEX HEAD BOLTS
6	½" HEX NUTS
6	½" LOCK WASHERS
12	½" FLAT WASHERS
1	DHD19-100 LEFT BRACKET
1	DHD19-100 RIGHT BRACKET

****Inspect bumper and all parts prior to installation.**

-WARNING-

Special care should be exercised in the handling and installation of our products.

- Always wear safety glasses during installation process to avoid personal injury.
- Use extreme caution when lifting and securing product into place.
- Never position yourself directly under product during installation.
- Insulate all exposed wiring and electrical connectors.
- Always securely mount wiring harness to bumper and vehicle.
- Products may require minor trimming for proper fit.
- Periodically check nuts and bolts to make sure they remain tight

INSTALLATION INSTRUCTIONS

- LOCATE & REMOVE FACTORY TOW-HOOKS.
- INSERT PROVIDED LEFT & RIGHT TS BRACKETS INTO THE FRAME RAIL, ATTACHING WHERE THE TOW-HOOKS WERE LOCATED, REUSING THE FACTORY TOW HOOK BOLTS. **NOTE: LEAVE ALL BOLTS LOOSE UNTIL GRILLE GUARD IS INSTALLED*
- LIFT & INSTALL THE TS GRILLE GUARD TO THE BRACKETS, USING THE PROVIDED ½" HARDWARE. THE BRACKETS MOUNT ON THE INSIDE OF THE GRILLE GUARD UPRIGHT.
- ALIGN, ADJUST & TIGHTEN ALL BOLTS.

